



echOsonix® U71/U73 Ultrasonic Transmitter

General Instructions

Table of Contents

Quick Start Installation Guide.....	2
Safety/Protection	4
Mounting Location	5
Mounting Methods.....	8
Focusing Cone and Flange Assembly.....	9
Installation - Electronics.....	10
Transducer Wiring	11
Integral Electronics Wiring.....	12
Wiring Diagram.....	13
Terminal Block Diagram.....	15
Modbus Wiring Diagram.....	16
Modbus Network.....	17
User Controls.....	18
Programming.....	18
Display Options	19
User-Defined Values.....	20
Menu Structure.....	22
Troubleshooting.....	24
Helpful Hints	27
Installation Drawings	28
Product Specifications.....	34
Model Number Description.....	35



U71



U73

echOsonix is a non-contact, ultrasonic level sensing device. It provides several product-handling functions in one device.


- Isolated 4-20 mA reversible analog output scaled over the range entered by the user
- Modbus digital communications
- Switch - Two (model U71 integral mount) or four (model U73 remote mount) programmable Form C SPDT relays
- Switch function choices of energize on high or low level, fail-safe or disabled
- Switch settings fully independent of level transmitter range and other relays
- All values entered in engineering units
- Push-button setup, no ranging or calibration required
- Field selected application type from liquid, slurry or solid
- Simulate mode to test parameter settings and relay/analog outputs
- Automated false echo handling
- Diagnostics - Features to aid installation/setup and provide testing and diagnostic functions

WARRANTY NOTICE

The PC boards are serialized to each unit and should not be removed except by the factory. Removing the PC board will render the warranty null and void.

Quick Start Installation Guide


Install the transducer away from obstructions. **Do not** mount in the center of domed or conical roof tanks. See page 5 for minimum mounting distance from tank walls.




Flanged Mounting



Avoid mounting end of transducer assembly inside standpipe.



Use a shorter standoff so end of transducer assembly is inside vessel, or...



Extend standpipe into the vessel and cut the end at a 45° angle.


Threaded Mounting



Avoid mounting end of transducer assembly inside standpipe.




Use a threaded coupling directly on top of the vessel, or...



Extend standpipe into the vessel and cut the end at a 45° angle.

See page 8 for standoff details.


Wire the unit according to local and national safety codes. Power and signal wiring must be run as a minimum. Refer to pages 10-15 for more wiring details. **NOTE: Proper earth grounding of electronics is critical!**



This guide is intended to be a quick reference only. Please refer to each section of this form for details on installation, wiring, set-up and operation. Contact the factory or your local representative if you have any questions or concerns.


Quick Start Installation Guide

To splice remote transducer cables, follow the diagram below. See page 11 for details.




Calculate the level distances for the vessel. These will be entered when programming the unit. All values are measured from the transducer face down to the desired level. See page 20-21 for details of each value.

NOTE: All values are measured from the transducer face down. Hi Level will be a smaller number than Lo Level.



Program the basic parameters in the setup menu. Press CAL to access the menu. Enter the Application Type, Hi Level, Lo Level and relay settings using the values calculated in the above step. See pages 22 and 23 for menu structure and description.



NOTE: Push-button interface is the same for integral and remote units.

NOTE: To change number values fast, hold down the arrow key and press CAL.

This guide is intended to be a quick reference only. Please refer to each section of this form for details on installation, wiring, set-up and operation. Contact the factory or your local representative if you have any questions or concerns.

Electrical Safety

The echOsonix is an electrically powered transmitter. Common electrical safety procedures must be followed when working with this equipment. All wiring should be per local and national standards. Do not remove the enclosure cover unless the area is known to be non-hazardous. Do not handle circuit boards when energized.

Sound Protection

The echOsonix produces intense sound pulses. SOR recommends checking local safety standards for Applicable hearing protection regulations.

Do not aim the transducer of an operating echOsonix at anyone's head. Permanent hearing damage may result. Use proper hearing protection when operating in an enclosed space.

Transducer Model/Frequency	SPL* at 3 ft. (1 m) in front of transducer	SPL* at 3 ft. (1 m) to side of unit	SPL* at 3 ft. (1 m) behind unit
A - 5kHz	137 dB	113 dB	100
B - 10kHz	138 dB	111 dB	
K - 15kHz	135 dB	107 dB	
C - 20kHz	135 dB	108 dB	
D - 30kHz	133 dB	102 dB	

*Sound Pressure Level

These values are based on dB (Lin) Peak, unweighted. Consult local sound protection standards for conversions and limits.

Electrostatic Discharge (ESD) Handling Procedure

The SOR electronics instruments are designed to the highest quality standards. These products use highly sensitive electronic components that are affected by static electricity, that is present in most work environments. The following procedure is recommended to reduce the possibility of component failure caused by static electricity damage.

1. Use a grounded wrist strap when installing or removing electronic boards. A grounded workstation is recommended.
2. Ensure that all electrical connections are made and none are partial or floating. Ground all equipment properly.
3. To prevent ignition from static charge buildup, use a damp cloth when cleaning the unit.

General


These instructions provide information for Mounting, Process and Electrical connections and Field Programming of the echOsonix transmitter.

The echOsonix incorporates a transducer for sending and receiving an ultrasonic signal and an electronics processing package. The ultrasonic signal is very powerful and may cause hearing damage - refer to the safety instructions above. The electronics package is either mounted on top of the transducer or in a remote location connected by a shielded cable.


Prior to installation, review these instructions entirely. Transducer mounting location is critical to proper operation. Most settings can be programmed prior to installation. Refer to these instructions and the model number definition on pages 35-36 to ensure that the model selected is suited to the intended application.

Mounting Location

For all applications the transducer is mounted above the process pointing directly down at the measured surface. In open or flat topped vessels the transducer should be mounted so that the primary cone of sound does not intersect the wall of the vessel, if possible. The table below lists typical guidelines for minimum mounting distances from the wall. If the radius of the vessel is less than the minimum distance, consult the factory for assistance.




For vessels taller than 40 feet (12m), use:
 $Minimum\ Distance = Vessel\ Height \times 0.087$



Mounting Location (continued)

Transducer mounting placement is critical. The transducer assembly generates both the sound pulse and monitors the echoes. The sound pulses travel away from the face of the transducer in a cone-shaped pattern. This area should be free of obstructions and away from inlets.


The transducer should be mounted in a position that allows unobstructed access between the face and the process to be measured. See figures below for guidelines.



NOTE: A good rule of thumb is to look down inside the vessel through the mounting location. You should be able to see a clear path to the process material without any physical objects or fill streams in the way.

Alternative Mounting

echOsonix units may be mounted inside a stilling well or bridle to avoid excessive obstructions or turbulence in the process. Follow the guidelines shown below for the stilling well or bridle, then see page 27 for unit setup instructions.




Mounting Location (continued)

echOsonix units are designed to read solids materials and ignore the angle of repose. The angle of repose is the angle between horizontal and the side of the pile of material. For processes where the angle of repose is greater than 45 degrees, the echOsonix may require some special tuning or setup. Contact the factory for these situations.

For solids installations, the echOsonix should be mounted in a vertical position according to the diagram below. Do not "aim" the transducer to the angle of repose, this is not necessary. Mount the transducer $\frac{1}{3}$ of the distance from the vessel wall to the vessel centerline, away from any internal obstructions.

For vessels that fill and discharge from the center, this mounting location will provide a good average level measurement. As solids pile up they form a cone, and as they discharge they form a conical pit. By measuring the level at the $\frac{1}{3}$ radius position shown, an average level is obtained for both situations. For vessels that do not fill and/or discharge from the center, a mounting location should be chosen that will provide the best possible average level.



Mounting Methods


echOsonix transducers may be mounted using a threaded connection or a flanged connection. Some units require flange mounting. There are two options for thread mounting which are detailed below. In all cases, the transducer should be installed in a stable, permanent mounting fixture.

Focusing Cones

All units are supplied with some form of focusing cone to be mounted on the transmitting end of the transducer. These cones should always be installed according to the instructions in this manual. If the mounting method inhibits this cone, the mounting should be modified to account for it. The cones are vital to proper performance and should not be modified or removed.

Thread Mounting

Short-range transducers (30, 20 and 15kHz) may be supplied with a 3" NPT mounting thread. All remote transducers are also supplied with a 1" NPT/BSP cable nipple that can be used for either conduit connection or mounting.




Note: Only use this mounting in low-vibration areas.

Flange Mounting

When mounting a unit with a flange, we recommend using non-metallic bolts. The mounting bolts should be hand-tight only. Do not over-tighten the bolts, this can affect performance of the echOsonix transducer.

Most flange mounts use a standpipe. It is important to follow the guidelines below for standpipe design. Methods are shown in order of preference - Method 1 preferred, etc.



Focusing Cone and Flange Assembly

Units supplied with focusing cones and flanges are shipped disassembled. Follow the directions below to assemble these units prior to installation.

STEP 4

For 10kHz (BBP, RBP, BEP), screw locking ring down tight onto top of focusing cone

Or

For 5kHz (BAP, RAP) locking ring is not moveable, screw transducer down until locking ring is tight onto top of focusing cone

STEP 3

Mount transducer into flange assembly.


STEP 2

Install mounting flange / focusing cone assembly into process.

STEP 1

Thread focusing cone into mounting flange.

NOTE: All threaded connections should be sealed with either Teflon tape or a thread sealer that is compatible with Polypropylene.



Electronic Housing Installation

For integral units, the electronic housing assembly is permanently attached to the transducer and mounted at the same time. This design unit is not considered here.

For remote units, the electronic housing is a separate assembly from the transducer. The two are attached by a 7-conductor, 22-gage shielded cable. The electronics enclosure should be mounted in a location that is protected from physical damage, will stay within the temperature limits of the electronics and is convenient to plant operators.


One cable gland is supplied with the unit for the transducer cable. Power and signal wiring must be routed through a customer supplied cable gland. Customer connections should be installed in the same housing surface as the supplied factory cable gland.

Customer Cable Gland Installation

1. Locate where the cable gland will be installed and mark the center of the hole. Clamp the enclosure to a secure surface. Drill the required hole size.

NOTE: Backing is NOT required when drilling the echOsonix remote electronics enclosure.


2. Open cover.
3. Remove all machining debris from inside the enclosure. Install the new cable gland.



Electronic Housing Installation (continued)

Mounting Remote Electronics Box

Mount the remote electronics enclosure so that the hinged cover is upright and opens from right to left. Mount the box using four threaded screws through the holes provided on the back (hole size 3/16").




Transducer Cable Installation

On remote mount units the electronics housing may be mounted up to 330 feet (100m) away from the transducer. Transducer cable is supplied with each unit to the length requested in the model number. The cable is sealed in the transducer and has six conductors at the electronics end.

Transducer cable should be mounted in conduit, but it is not required. Mount the cable so that it is free from physical damage and electrical interference from outside sources. The transducer cable should always be mounted away from high-energy AC power lines. Splices in the cable must be protected from weather. If conduit is used, it is NOT necessary to use grounded, metal conduit.

If the cable is too short, it can be lengthened in the field. Extend the cable length using 6-conductor, 22-gauge shielded cable. The new cable may be attached with an in-line splice or using a junction box. Be sure to maintain color continuity.

If the cable is too long, it can be shortened in the field. Follow the diagram below very carefully to ensure proper termination of the cable. This is critical to the functioning of the transducer.



Integral Electronics Wiring

Remote transducer cables must be attached to the terminal block provided inside the remote electronics housing. The terminals are labeled on the PCB according to the wire colors: black, red, white, blue, green, yellow or orange. Thread the transducer cable through the factory supplied cable gland. Firmly attach each transducer wire lead to the corresponding terminal block point. Provide enough cable slack inside the housing to keep all stress off of the terminal connections. Tighten the cable gland nut securely – DO NOT OVERTIGHTEN.

NOTE: To ensure proper and secure wiring, back each terminal block screw out to the fully open position before inserting the appropriate wire. After tightening the terminal screw, check the connection by gently tugging on the wire to see if it comes out of the terminal block.


The echOsonix may be powered by 24 VDC, 110/220 VAC or both at the same time. The most common method of powering the unit is to use 110 VAC line power with a 24 VDC battery backup. The unit has an optically isolated 4-20mA analog output signal, RS485 Modbus digital communications output and two or four relays.

CAUTION: Electrical power must be disconnected from explosion proof models before the cover is removed. Failure to do so could result in severe personal injury or substantial property damage.

Integral Housing Wiring

1. Loosen cover locking screw A1 and remove cover A2 to access display board B.
2. Remove the display board by removing the three screws at its outer edge C. DO NOT remove the four screws at the corners of the LCD display. Pull the display board up and lay it out of the way.
3. Remove the terminal blocks D by rocking them back and forth gently while pulling straight up. Run the supply wires through conduit opening E and attach them to the terminal blocks per the wiring diagram selected from pages 13 – 14.
4. After wiring is complete, align the respective terminal block with its socket and push firmly into place. The entire block must be fully seated for proper connections.
5. For explosion proof locations, install the proper conduit seals per local and national codes and standards.

NOTE: Minimum recommended wire gage should be 14 AWG. Conductors are rated for 100°C minimum.



Drawing 0390733


Wiring Diagrams

All echOsonix units may be powered by either AC or DC external supplies. The analog 4-20mA circuit may either be powered from the echOsonix internally or by a user-supplied external DC power supply. The wiring diagrams below specify the wiring options for either 3-wire DC, 4-wire DC or AC external power supplies.

The analog 4-20mA circuit is a self-powered, optically isolated negative side current control loop. The current is actually controlled between the "I COM" and "I-" terminals of the unit. The "I+" terminal is the internally regulated voltage source for self powering the current loop. The loop is approximately +17V above the output common "I COM".


Terminal Connections for DC Supply

- a) 3-Wire DC – 4-20mA driven from Common User Supply (RL to +DC)




Note: RL max = 700Ω if user DC Supply ≥18V

- b) 3-Wire DC – 4-20mA driven from Common User Supply (RL to GND)



Note: RL max = 700Ω if user DC Supply ≥18V


- c) 4-Wire DC – 4-20mA driven from Internal Isolated Supply (I+)



Note: Isolated current output can be made common with +DC or GND if required. (e.g. RL – connected to GND)


Terminal Connections for AC Supply

d) 4-20mA driven from User's External DC Supply (RL to Pos.)




Note: $RL_{max} = 700\Omega$ if user DC Supply $\geq 18V$

e) 4-20mA driven from User's External DC Supply (RL to Neg.)




Note: $RL_{max} = 700\Omega$ if user DC Supply $\geq 18V$

f) 4-20mA driven from Internal Isolated Supply (I+)



Note: Isolated current output can be made common with external DC Supply Pos. or Neg. if required. (e.g. RL - connected to GND)

Integral Terminal Block Diagram





Terminal	Description
Test	Test port (factory only)
GND	-DC power
+DC	+DC power
GND	AC ground
Neutral	AC neutral
Active	AC hot wire
RL1NC	Relay 1 normally closed
RL1C	Relay 1 common
RL1NO	Relay 1 normally open
RL2NC	Relay 2 normally closed
RL2C	Relay 2 common
RL2NO	Relay 2 normally open



Terminal	Description
A	RS485 Comm Port
B	RS485 Comm Port
GND	Ground point
I+	4-20 mA loop positive pole
I-	4-20 mA loop negative pole
ICOM	4-20 mA loop common

Remote Terminal Block Diagram



Terminal	Description	Terminal	Description	Terminal	Description
1	Relay 1 normally open	11	Relay 4 common	YLW	Yellow transducer wire
2	Relay 1 common	12	Relay 4 normally closed	485A	RS485 Comm Port
3	Relay 1 normally closed	13	AC hot wire	485B	RS485 Comm Port
4	Relay 2 normally open	14	AC neutral	GND	Ground point
5	Relay 2 common	15	AC ground	ICOM	4-20 mA loop common
6	Relay 2 normally closed	BLK	Black transducer wire	I-	4-20 mA loop negative pole
7	Relay 3 normally open	RED	Red transducer wire	I+	4-20 mA loop positive pole
8	Relay 3 common	WHT	White transducer wire	TST	Test port (factory only)
9	Relay 3 normally closed	BLU	Blue transducer wire	GND	-DC power
10	Relay 4 normally open	GRN	Green transducer wire	+DC	+DC power


Modbus Wiring Diagram

All line-powered echOsonix units are provided with Modbus communications. One advantage of this feature is the ability to connect units in series, reducing cabling requirements. Up to 128 echOsonix units may be connected through a single I/O point using the Modbus communications network. The wiring diagram below describes how to do this.

Materials Required

- Three conductor shielded cable
- An RS485 compatible computer control system with external AC or DC power supply
- OR -
- An ADAM RS485 to RS232 converter (or equivalent) and PC with available Serial port

NOTE: This wiring diagram is for the Modbus communications ONLY. Either AC or DC power must be provided separately. Power circuits may be connected in series as well; each echOsonix unit will draw approximately 0.3A.



Modbus Network

Each echOsonix has a communications address that must be unique. The Modbus protocol uses this address to identify each unit. The default address “1” must be changed before connecting more than one unit to the network. This can be done either through the on-board menus or the Modbus interface. Follow one of the procedures below to address each unit before connecting them all to the network.

On-Board Menu Procedure

1. Provide power to the unit.
2. At the normal operations screen on the LCD, press CAL once. The screen will change to “UnLock: 0”.
3. Use the up arrow to enter “195” for the unlock code. Press CAL once. The screen will change to “Setup”.
4. Press the up arrow twice to change the screen to “Tracking”. Press CAL once.
5. Press CAL until the screen says “CommAdd: 1”. This is the communications address value.
6. Press the up arrow to enter the unique communications address for this unit – range is 1 to 255. (**NOTE:** Do not use addresses 3 or 6.)
7. Press RUN to save the communications address.
8. Repeat this procedure for every unit in the network, making sure each one has a unique address.

Modbus Interface Procedure

1. Connect one unit to both the power supply and the Modbus network per the prior wiring diagram.
2. Set up the controlling computer software to write to the Comms Address parameter per the chart below.
3. Write a unique communications address to this unit. This address must be between “2” and “255”.
4. Connect one more unit to both the power supply and the Modbus network.
5. Repeat steps 3 and 4 until all units have been connected to the network and given a unique address.

Modbus Address Definitions

Many users will want to connect echOsonix units to their pre-existing Modbus compatible control system. To do this, they must know what information is available over the Modbus network, where it is located, and how to manipulate it. The chart below defines the most commonly used addresses on the echOsonix unit. It is not the intention of this document to educate users on the fundamentals of Modbus protocols. More information can be found at www.modbus.org.

echOsonix Parameter	Command Address	Location	Decimal Min.	Decimal Max.	Conversion Factor	Description
Read Only Parameters						
Distance	75	High byte Low byte	0	46562	See below	Current output of the unit as distance from the face of the transducer to the process material.
Noise Level	79	Low byte	1	255	X 0.3922	The background noise detected by the transducer
Temp	70	High byte Low byte	0	1760	Divide by 10	Currently monitored temperature in °F or °C (based on units of measure selected).
Temp Sign	18	High byte	NA	NA	NA	If bit 3 = 1, temperature is positive, if bit 3 = 0, temperature is negative.
Read/Write Parameters						
Comms Address	65	High byte	1	255	1	Communications address for the unit as described above.
Units of Measure	18	High byte	NA	NA	NA	If bit 0 = 1, units is feet, if bit 0 = 0, units is meters.
Display	35	High byte	0	2	NA	0 = distance, 1 = level, 2 = level %
Application	22	High byte	0	2	NA	0 = solids, 1 = liquids, 2 = slurries
Application Speed	22	Low byte	2	255	X 0.1 (ft) X 0.03 (m)	The maximum speed the process is expected to move.
Damping	20	Low byte	0	240	1	Damping value
Blanking	33	High byte Low byte	0	46562	See below	Programmed blanking distance

NOTE: Additional echOsonix parameter address information is available from the factory.

Distance Conversion Factors


To convert distance values from decimal form to engineering units, multiply the reported result by the following factors.

Transducer Frequency/Model	Conversion to Feet	Conversion to Meters
5 & 10kHz (RAP, BAP, RBP, BBP)	0.001501333	0.0004576
15, 20 & 30kHz (RKP, BKP, RCP, BCP, RDP, BDP)	0.00011439	0.0003753

User Controls


The echOsonix requires a minimal amount of parameter setup. The units, display, process type and range must be set for each application. All other parameters should be set as required or desired. The large picture below shows the setup interface for an integral unit. The remote unit controls are shown in the inset. The next section shows the menu choices as well as a brief description of each feature.

NOTE: When changing **numerical values**, hold down the **arrow** button and push the **CAL** button to make the numbers change faster. But be careful – if you let go of the **arrow** while pushing the **CAL** button the display will move to the next programming step.



Programming

The echOsonix uses a menu structure that is accessible through the four-button keypad. Information is displayed on the 2-line LCD, with the program option displayed on the top line and the current setting displayed on the lower line. Button functions are consistent for all models.



“RUN” Button

The “RUN” button returns the unit to normal operation mode. This button will exit the menus at any point, saving the current selected options and entering normal operation.

WARNING: Units in Hazardous Locations — Prior to calibration, make sure that the work area is declassified before removing the explosion proof cover to program the unit. Failure to do so could result in severe personal injury or substantial property damage.

“↑” and “↓” Buttons

The “↑” and “↓” buttons are used to change numerical values and menu option choices. When changing numerical values, the rate of change can be increased by also pressing and holding the “CAL” button (see below).

“CAL” Button


The “CAL” button is used to enter the menus and move between programming options. Press the “CAL” button from normal operation mode to enter the password screen. Once in the menu screens, use the “↑” and “↓” buttons to make your choice, then press the “CAL” button to accept that choice and move to the next programming option. When changing numerical values, hold down the “↑” or “↓” button and press the “CAL” button to speed up the number change.

Display Options

Every echOsonix includes a two line LCD display. This serves as a display of process level, an interface for programming and provides diagnostic information. There are three LCD display modes: normal operation, programming and diagnostic.

Normal Operation


In normal operation the top line shows the Display Mode selected in the programming setup – Distance, Level or Level %. The second line displays the actual level reading. The decimal character used in the number displayed signifies what state the unit is in. The unit can always be returned to normal operation by pressing the **RUN** key.



Programming Mode


In programming mode the top line of the display indicates what feature is being programmed. The bottom line shows the current choice for that feature. Move from feature to feature using the **CAL** key, choices are changed using the arrow keys.

NOTE: Be sure to press the **RUN** key to exit menus. Outputs are locked in place and will not respond to level changes in Programming Mode.



Diagnostic Mode

When the unit is in normal operation, diagnostic information is displayed by pressing the up arrow key. The top line of the LCD changes to the diagnostic information, the lower line continues to display the level reading. See below for details.




Diagnostic Screen

When the unit is in normal operation, several diagnostic features can be accessed by pressing the “**↑**” button. The top line of the display will scroll through five items detailed here as the “**↓**” button is pushed. The bottom line of the display will continue to show the normal output. Accessing the diagnostic feature will not affect analog or relay outputs.

Datum	Description
GN	Gain being currently applied to the received echo. (Includes GR below.)
GR	Amount of recover gain currently being added to the normal gain curve.
NL	Background or electrical noise detected by the transducer. If the unit is behaving erratically, noise may be the problem.
T	Temperature detected at the face of the transducer. This is displayed in Fahrenheit or Celsius depending on the units of measurement selected (feet or meters).
E	The actual distance currently being detected, regardless of damping or window location.

User-Defined Values

Several user-defined values must be entered in the following menu. The figure below illustrates what these values are and how they are determined. It is important to remember that all distance values are measured from the sensor face down in all menus. This figure assumes 4-20 mA output and no offset.




* The 4-20 mA output can be reversed to 20-4 mA in the Trim menu. See page 23.

**L1 and L2 relay settings can be set outside of the range of the Hi Level and Lo Level.

User-Defined Values


Each echOsonix unit is supplied with Form C contact SPDT relays. In the Setup menu the action of these relays and the points in the measured range where they change state is programmed. The charts below assist in determining how to program each relay to your requirements.



*For failsafe condition, use relay setting indicated for desired process state.




Menu Structure

The echOsonix is programmed and tested through two menus. A third menu is used to alter the automated features - consult the factory for access to this menu.



Setup Menu


User-defined values are entered in the setup menu. The transmitter is programmed for the specific application it will be used in, including process levels.



Menu Structure (continued)

Trim Menu

Many applications require the instrument to be fine-tuned for the existing conditions. The Trim menu allows adjustment of output signals, process condition parameters and signal processing for difficult conditions.




Troubleshooting

echOsonix units use an increasing gain curve, or sensitivity curve, to detect echoes. As an echo comes from a target at a longer distance from the transducer, the gain applied to that echo increases. This allows the unit to compensate for sound strength losses from distance. Some of the values that define this gain curve are constant in all but the most challenging applications and should only be adjusted by factory-trained personnel. Other values can be adjusted as needed to solve minor problems. These values are found in the "Trim" menu under the "Gain Trim" section as seen on page 23.

The users section of the gain curve starts at or near the end of the standard blanking distance. The gain increases in a sharp curve to the value "Gain Step" or GS at the "Distance Step" or DS from the face of the transducer. This section is typically used to eliminate false echoes close to the top of the measurement range. At the distance DS the gain has increased to the "Gain Normal" or GN value. From here the gain increases in a gradual curve to its maximum value at a distance beyond the end of the measured range. The GN value is typically used to eliminate false echoes in the mid-range portion of the application or to increase the sensitivity for difficult applications.

The diagram below illustrates how the gain curve, GS, DS and GN relate to a sample application. As you can see, the gain increases in the two sections as the distance increases from the transducer face to the measured process. See page 26 for tips on how to adjust these values to resolve certain situations.




Troubleshooting (continued)

Aside from the gain curve, the echOsonix has a value called "Threshold" or Thld that allows it to determine what strength echo it will accept. The unit converts echoes from sound energy into voltage, and monitors echoes from 0 to +3.0 Volts DC. The Thld value sets the strength of echo that will be accepted as the valid echo to be tracked by the transmitter.

The Threshold (Thld) value default is 0.30 VDC. It must never be set lower than 0.30 VDC or higher than 2.5 VDC to ensure proper operation of the unit.

The diagram below is an example of echoes received in the tank shown as seen on an oscilloscope. In this case, a threshold value of 1.00 VDC will ignore the inlet pipe but will read the process echo. Consult the Troubleshooting guidelines on page 26 before making adjustments to this value.



Troubleshooting (continued)

The gain curve and threshold settings previously discussed can be used to modify the echOsonix for difficult installations, to eliminate false echoes and to increase sensitivity in tough applications. There are many other potential situations that can be corrected by other means. The next section of this manual, “Helpful Hints”, covers some ideas on how to troubleshoot problems and some suggested ways to correct them.


The flowcharts below give suggested ways to correct specific problems using the values found in the “Trim” menu under the “Gain Trim” section as seen on page 23. In many instances the values in that menu must be changed in combinations of two or more to get the desired effect. The charts below are intended to be guidelines for doing this, not hard and fast rules. Each installation and application is unique and may require a unique combination of parameter settings to solve a problem.

If your application is working properly and track the process correctly, do not modify these settings.


When making changes to these parameters, the top line of the display shows the actual value, and the bottom line show the distance from the sensor face to the echo the unit is currently reading. It is important to know the correct distance you are trying to obtain while troubleshooting so that you know when the changes you are making have the desired effect.

If the suggestions given below do not solve the problem, contact a factory technician for assistance.


Problem: When the process level is low, the unit seems to keep jumping up to a higher level reading.




Problem: When the process level is high, the unit seems to keep jumping down to a lower level reading.



Problem: The unit loses track of the process during filling/emptying only.



Problem: The unit keeps reading the end of my flange standpipe, not the process.



Helpful Hints

The following is a collection of tips gathered from experience to help ensure optimal performance in a variety of situations. Consider them all and use them as necessary since some may not apply to every circumstance.

General Installation

- Installation is the key to performance in all cases. Improper installation or failure to follow the installation instructions accounts for the vast majority of performance problems. The echOsonix is designed to adapt to various situations and proper installation will significantly improve the performance.
- When mounting the unit to the mating nozzle flange, it is recommended that a plastic flange with plastic bolts be used and, if possible, a rubber gasket. The bolts should only be tightened enough to keep the unit in place.
- The echOsonix will not read through solid surfaces such as a window. Neither can it read a solids level through a liquid level (e.g. a sludge settling basin).
- If there is no display upon wiring, check the following:
 - Is there power to the unit?
 - Is the unit properly wired? Are the wires secure (check by gently tugging on them with pliers)?
 - If using a DC power supply, is at least 24VDC supplied at the terminal block?
 - Are the fuses both good (AC and DC fuses)? They can be checked with an ohmmeter.

Special Installations


- The echOsonix can be mounted above a grating or decking. There are certain mounting requirements and parameter changes to make:
 - The unit should not physically touch the grating. Mount the unit above the deck at least 6" (300mm). This will prevent excessive noise caused by interference with the grating.
 - The "Blanking" distance should be extended past the lower surface of the grating.
 - Make sure the decking is not a solid surface – it must have at least 50% of its surface area as open holes.
- When the echOsonix is **mounted inside a stilling well or bridle**, there are some parameter changes that must be made to allow proper performance. These devices provide intense focusing of echoes and it is very easy to overwhelm the transmitter if these changes are not made:
 - Decrease GS to approximately 3 – 5%.
 - Increase DS to approximately 1 foot (300mm) longer than the stilling well or bridle.
 - If having difficulty with erratic readings after making the two changes above, increase the THLD to 1.0 VDC.
 - *Note: Stilling wells and bridles should be minimum 4" (100mm) inside diameter and maximum 20 feet (6m) long.*
- If the output is erratic due to turbulence, intermittent obstructions, etc., decrease the "Speed" setting to the maximum possible rate of level increase, then increase the "Damping" parameter until acceptable stability is achieved.

Programming


- Remember that all distance values are measured downward from the sensor face in all menus. This means that even if you are displaying Level or Level %, the Hi Level, Lo Level and relay settings are still input and displayed as distance from the sensor face down.
- In most cases the "Blanking" distance should be increased to a value slightly less than "Hi Level". This will eliminate the possibility of false echoes above the measured range. Do not use a blanking value less than the stated minimum.

Dimensions

Remote Electronics 30 kHz Transducer




Remote Electronics 20 kHz Transducer




Dimensions

Remote Electronics 15 kHz Transducer




Remote Electronics 10 kHz Transducer



Dimensions


Remote Electronics 5 kHz Transducer



Drawing 0390628

Dimensions

Integral Electronics 30 kHz Transducer




FC Option
Drawing 0390629

NOTES:
 1. SIGHT GLASS COVER SHOWN. SUBTRACT 0.52 INCHES (13.2 MM) FROM THIS DIMENSION FOR HOUSINGS WITH BLIND COVERS.

Dimensions = $\frac{\text{mm}}{\text{in.}}$

Integral Electronics 20 kHz Transducer




FC Option
Drawing 0390630

NOTES:
 1. SIGHT GLASS COVER SHOWN. SUBTRACT 0.52 INCHES (13.2 MM) FROM THIS DIMENSION FOR HOUSINGS WITH BLIND COVERS.

Dimensions = $\frac{\text{mm}}{\text{in.}}$

Dimensions

Integral Electronics 15 kHz Transducer




NOTES:

1. SIGHT GLASS COVER SHOWN. SUBTRACT 0.52 INCHES (13.2 MM) FROM THIS DIMENSION FOR HOUSINGS WITH BLIND COVERS.

Dimensions = $\frac{\text{mm}}{\text{in.}}$

FC Option Drawing 0390646

Integral Electronics 10 kHz Transducer



NOTES:


1. SIGHT GLASS COVER SHOWN. SUBTRACT 0.52 INCHES (13.2 MM) FROM THIS DIMENSION FOR HOUSINGS WITH BLIND COVERS.

Dimensions = $\frac{\text{mm}}{\text{in.}}$

Drawing 0390631

Dimensional Drawings

Integral Electronics 5 kHz Transducer



NOTES:

1. SIGHT GLASS COVER SHOWN. SUBTRACT 0.52 INCHES (13.2 MM) FROM THIS DIMENSION FOR HOUSINGS WITH BLIND COVERS.
2. DIMENSIONS SHOWN AT MINIMUM VALUES. DIMENSIONS CAN INCREASE BY AS MUCH AS $\frac{1-1/4}{31.8}$. DIMENSIONS ARE BASED UPON THE POSITION OF THE TUNING RING SET POINT.

Drawing 0390632

Dimensions = $\frac{\text{mm}}{\text{in.}}$

Product Specifications

Electronics

Operating voltage	110 VAC version	22 – 27 VDC and/or 100 – 126 VAC
	220 VAC version	22 – 27 VDC and/or 200 – 230 VAC
Power consumption	24 VDC power supply.....	<10 W
	110/220 VAC power supply	<10 VA
Relay output	Integral version.....	2 Form 'C' (SPDT) Contacts Rated 10A @ 240 VAC
	Remote version	4 Form 'C' (SPDT) Contacts Rated 10A @ 240 VAC
<i>All relays have independently adjustable deadbands.</i>		
Analog output	4 – 20 mA or 20 – 4 mA	(700 ohm Loop resistance)
Digital output	Modbus	
Electronic accuracy	±0.25% of Maximum Range	
Remote cable length	<100m (334 ft.)	
Remote cable type	TYCAB DMC 71402 or Carol Cable CO764 7 conductor, 22 Ga. shielded cable	
Display	2 Line 8 Character LCD Display	
Memory	Non-Volatile with >10 Years Retention	
Electrical connections	2 x ¾" NPT(F) on Integral Units	
Hazardous area classification	EEx md IIB + H2 (Integral only)	

*Design and specifications are subject to change without notice.
For latest revision, see www.sorinc.com*

Transducers

Transducer Model/Frequency	Blanking Distance	Maximum Liquid/Slurry Range	Maximum Solid/Power Range
A - 5kHz	60 in. (1.52m)	260 ft. (80m)	260 ft. (80m)
B - 10kHz	48 in. (1.22m)	260 ft. (80m)	100 ft. (30m)
K - 15kHz	24 in. (0.61m)	65 ft. (20m)	33 ft. (10m)
C - 20kHz	24 in. (0.61m)	65 ft. (20m)	33 ft. (10m)
D - 30kHz	18 in. (0.46m)	33 ft. (10m)	10 ft. (3m)
Transducer Model/Frequency	SPL* at 3 ft. (1 m) in front of transducer	SPL* at 3 ft. (1 m) to side of unit	SPL* at 3 ft. (1 m) behind unit
A - 5kHz	137 dB	113 dB	100
B - 10kHz	138 dB	105 dB	
K - 15kHz	135 dB	107 dB	
C - 20kHz	132 dB	108 dB	
D - 30kHz	129 dB	102 dB	

*These values are based on dB (Lin) Peak, unweighted. Consult local sound protection standards for conversions and limits.

Maximum operating pressure 15 psig (1.0 BAR)

Operating temperature

Integral Unit Display.....	-40°F (-20°C) to 140°F (60°C)
Integral Unit Electronics.....	-40°F (-40°C) to 140°F (60°C)
Remote Display.....	+14°F (-10°C) to 140°F (60°C)
Remote Electronics.....	-40°F (-40°C) to 140°F (60°C)
Remote Transducer	-40°F (-40°C) to 140°F (60°C)

Model Number Description — Electronics Model Number

						6 Input Power			
		5 Level Measurement		L		7 110 VAC and / or 24 VDC			
						8 220 VAC and / or 24 VDC			
		4 Housing				7 Output Type			
		NEMA 4 / Explosion Proof with Window (integral only)		C		J 4-20 mA with Discrete Outputs			
		NEMA 4 / Explosion Proof without Window (integral only)		D					
		NEMA 4X (remote only)		F					
		3 Mounting				8 Agency Approvals			
		Integral		1		ZZ All Agency Listings			
		Remote		3		00 None			
		2 Power Type				9 Transducer Frequency			
		Line Powered		7		30 30 kHz			
						20 20 kHz			
						15 15 kHz			
						10 10 kHz			
						05 5 kHz			
1 echOsonix Transmitter								10 Accessories	
U								PP Paper Tag	
								RR Wired on SS Tag	
								VV Fungicidal Varnish on Housing	
U	7	1	C	L	7	J	00	30	PP Model Number

Model Number Description — Transducer Model Number

Process Connection Size		14	
3" (standard on 15/20/30 kHz transducers)		3	
4" (flange only - required for FC option on 15/20 kHz and T material of construction)		4	
6" (flange only)		6	
8" (flange only)		F	
10" (flange only - standard on 5/10 kHz transducers)		G	
Sensor Material of Construction		13	
Polypropylene		P	
Teflon wetted parts (30 kHz only)		T	
Transducer Range		12	
5 kHz - 260 ft. (80m) liquids/slurries/solids	A		
10 kHz - 260 ft. (80m) liquids/slurries, 100 ft. (30m) solids	B		
15 kHz - 65 ft. (20m) liquids/slurries, 33 ft. (10m) solids	K		
20 kHz - 65 ft. (20m) liquids/slurries, 33 ft. (10m) solids	C		
30 kHz - 33 ft. (10m) liquids/slurries, 10 ft. (3m) solids	D		
Transducer Type		11	
Integral Mount	B		
Remote Mount	R		
	B	D	P
			3
			A
			00
			xxx.x
			FC
			Model Number
Process Connection Type		15	
A	NPT Pipe Thread (3" size only)		
C	150# ANSI Flange (material to match sensor material)		
Agency Listings		16	
ZZ	All Agency Listings		
00	None		
Cable Length		17	
xxx.x	Remote transducer cable length in feet (334 ft. maximum)		
00000	Integral transducer (no cable required, use 0's to fill)		
Accessories		18	
FC	Focusing Cone for 15/20/30 kHz transducers (Requires 4" flange for 15/20 kHz)		
PP	Paper Tag (remote only)		
RR	Wired on SS Tag (remote only)		

